



EDGE 2 IoT LPWA Solution Industrial LTE-M/NB-IoT Edge Node

User's Guide

All Rights Reserved

Dissemination or reproduction of this document, or its contents, is not authorized except where expressly permitted. Violators are liable for damages. All rights reserved, for the purposes of patent application or trademark registration.

Disclaimer of Liability

The information contained in this document is subject to change without notice. EtherWAN is not liable for any errors or omissions contained herein or for resulting damage in connection with the information provided in this manual.

Registered Trademarks

The following words and phrases are registered Trademarks of EtherWAN Systems Inc.

EtherWAN

All other Trademarks are property of their respective owners.

Warranty

For details on the EtherWAN warranty replacement policy, please visit our web site at: www.etherwan.com

Contact EtherWAN Systems

8F., No.2, Alley 6, Lane 235, Baoqiao Rd. Xindian District, New Taipei City 231 Taiwan Tel: +886 -2- 6629-8986 Email: <u>info@etherwan.com.tw</u>

Preface

Audience

This guide is designed for the person who installs, configures, deploys, and maintains the Ethernet network. This document assumes the reader has moderate hardware, computer, and networking skills.

Document Revision Level

This section provides a history of the revision changes to this document.

Revision	Document Version	Date	Description
А	Version 1	01/10/2020	First release
В	Version 1	11/17/2020	Battery and Bluetooth removed from contents
С	Version 1	02/04/2021	Functions extended

Preface	
Chapter 1 Introduction	
1.1 Introduction	
1.2 Contents List	
1.2.1 Package Contents	7
1.2.2 Optional Accessories	7
1.3 Hardware Configuration	
1.4 LED Indication	
1.5 Installation & Maintenance Notice	
1.5.1 SYSTEM REQUIREMENTS	
1.5.2 WARNING	
1.5.4 Product Information for CE RED Requirements	
1.6 Hardware Installation	
1.6.1 Open the Top Cover	14
1.6.2 Insert SIM Card	16
1.6.3 Install Battery (Optional Accessory)	
1.6.4 Connecting to External Devices	
1.6.5 Connecting Console Port for PC Configuration Tool	
1.6.6 Power On the EDGE 2	
1.6.7 Setup with Windows-based Configuration Tool	
1.6.8 Device Mount and Screw Back the Top Cover	
Chapter 2 Device Configuration	
2.2 LDWA Configuration	
2.2 Li wa Configuration	
2.4 Modbus Configuration	
2.4 Module Configuration	
2.5 Schedule Configuration	
2.6 Event Configuration	
2.7 Server Configuration	
2.8 Log Format	
2.9 System Configuration	
2.10 CLI	

Chapter 3 Data and Command Formats	
3.1 Data Log Format	
3.2 Downlink Command Format	
Contact Information	

Chapter 1 Introduction

1.1 Introduction

Congratulations on your purchase of this outstanding product: Industrial LTE-M/NB-IoT Edge Node. For IoT applications, EtherWAN's EDGE 2 is absolutely the right choice. With built-in world-class LPWA module^{*1}, you just need to insert a SIM card from a local mobile carrier to get to remote servers on the internet.

The EDGE 2 is a cost-effective low complexity solution for simple data acquisition and wireless telemetry. The advanced LPWA, either Cat.M1 or NB1, is optimized for low bandwidth IoT traffic and leverages existing 4G infrastructure to transmit data at low data rates. It allows massive deployment of wireless IoT with carrier-level security. Thanks to the power saving technology, the EDGE 2 has ultra-low power consumption which allows it to operate on a single battery for years^{*2}.

Main Features:

- Simple device with various interfaces (AI / DI / RS-485) for IoT field data acquisition.
- Storage of the meter/sensor readings in non-volatile memory of the data logger.
- Transfer of logged data to designated remote server by schedule rule, or on an event at the site.
- Automatic issuing of low battery power alerts to remote server for device or battery replacement.
- Configuring via a PC with a convenient configuration utility.
- Water-resistant, dust-resistant IP65 enclosure for installing in severe environments.

Before you install and use this product, please read this manual in detail.

¹ EDGE1 for LoRa; EDGE 2 for Cat.M1/NB1(NB-IoT).

² The battery lifespan depends on actual usage (frequency of data logging, and data uploading) of the data logger.

1.2 Contents List

1.2.1 Package Contents

#Standard Package

ltems	Description	Contents	Quantity
1	EDGE 2 LTE-M/NB-IoT Edge Node	Constructions	1pcs
2	Al Jumper	444	Зрсs
3	Water/Dust-proof Stopper	111	3pcs

1.2.2 Optional Accessories

#Optional parts (these parts are sold separately)

Items	Description	Contents	Comments
1	USB-to-Serial Console Cable		Used for wired configuration
2	Battery	And a line in a line And a line in a line Surv C SIZE CR2550	1pcs

These parts are sold separately. If necessary, please contact us via <u>info@etherwan.com.tw</u>

1.3 Hardware Configuration

Front View



1.4 LED Indication



LED Icon	Indication	LED Color	Description
LED	Device Status	Blue / Red	 Steady OFF: Device is powered off. Red Steady ON: Device is booted up, but WAN not connected yet. Blue Flash: Device is booted up, and connected to WAN. Red Flash: Battery Low, or no SIM card while device is not in sleep mode. Blue and Red Steady ON: Device is in Recovery mode, or Firmware is upgrading

1.5 Installation & Maintenance Notice

1.5.1 SYSTEM REQUIREMENTS

Network Requirements	ISP provided SIM card for 4G LPWA service
Configuration Tool Requirements	 Computer with the following: Windows®7 or Windows 10 An installed Ethernet adapter A USB 2.0 or later interface for serial console

1.5.2 WARNING

•	Only use the battery that comes with the package or
\wedge	an external DC Power Supply that complies with the
	device specifications. Using a different voltage rating
	power adaptor is dangerous and may damage the
	product.
Attention	DO NOT remove or repair the control board by
	yourself. If the product is too hot or malfunctioning,
	turn off the device and have it repaired at a qualified
	service center.
•	Place the product on a stable surface, or screw it to a
	solid plate or wall.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FOR PORTABLE DEVICE USAGE (<20m from body/SAR needed)

Radiation Exposure Statement:

The product comply with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

FOR MOBILE DEVICE USAGE (>20cm/low power)

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FOR COUNTRY CODE SELECTION USAGE (WLAN DEVICES)

Note: The country code selection is for non-US models only and is not available to US models. Per FCC regulation, all Wi-Fi products marketed in US must be fixed to US operation channels only.

1.5.4 Product Information for CE RED Requirements

The following product information is required to be presented in product User Manual for latest CE RED requirements.³

(1) Frequency Band & Maximum Power

1.a Frequency Band for Cellular Connection (for BC66 Version)

Band number	Operating Frequency	Max output power
LTE FDD BAND 1	Uplink: 1920-1980 MHz	
	Downlink: 2110-2170 MHz	
LTE FDD BAND 2	Uplink: 1850-1910 MHz	
	Downlink: 1930-1990 MHz	
LTE FDD BAND 3	Uplink: 1710-1785 MHz	
	Downlink: 1805-1880 MHz	
LTE FDD BAND 5	Uplink: 824-849 MHz	
	Downlink: 869-894 MHz	
LTE FDD BAND 8	Uplink: 880-915 MHz	
	Downlink: 925-960 MHz	
LTE FDD BAND 12	Uplink: 699-716 MHz	
	Downlink: 729-746 MHz	22 ±2 dBm
LTE FDD BAND 13	Uplink: 777-787 MHz	ZS IZ UDIII
	Downlink: 746-756 MHz	
LTE FDD BAND 18	Uplink: 815-830 MHz	
	Downlink: 860-875 MHz	
LTE FDD BAND 19	Uplink: 830-845 MHz	
	Downlink: 875-890 MHz	
LTE FDD BAND 20	Uplink: 832-862 MHz	
	Downlink: 791-821 MHz	
LTE FDD BAND 25	Uplink: 1850-1915 MHz	
	Downlink: 1930-1995 MHz	
LTE FDD BAND 28	Uplink: 703-748 MHz	
	Downlink: 758-803 MHz	

1.b Frequency Band for Cellular Connection (for BG96 version)

Band number	Operating Frequency	Max output power
LTE FDD BAND 1	Uplink: 1920-1980 MHz	
	Downlink: 2110-2170 MHz	
LTE FDD BAND 2	Uplink: 1850-1910 MHz	23 ±2 dBm
	Downlink: 1930-1990 MHz	
LTE FDD BAND 3	Uplink: 1710-1785 MHz	

3 The information presented in this section is ONLY valid for the EU/EFTA regional version. For those non-CE/EFTA versions, please refer to the corresponding product specification.

	Downlink: 1805-1880 MHz	
LTE FDD BAND 5	Uplink: 824-849 MHz	
	Downlink: 869-894 MHz	
LTE FDD BAND 8	Uplink: 880-915 MHz	
	Downlink: 925-960 MHz	
LTE FDD BAND 12	Uplink: 699-716 MHz	
	Downlink: 729-746 MHz	
LTE FDD BAND 13	Uplink: 777-787 MHz	
	Downlink: 746-756 MHz	
LTE FDD BAND 18	Uplink: 815-830 MHz	
	Downlink: 860-875 MHz	
LTE FDD BAND 19	Uplink: 830-845 MHz	
	Downlink: 875-890 MHz	
LTE FDD BAND 20	Uplink: 832-862 MHz	
	Downlink: 791-821 MHz	
LTE FDD BAND 28	Uplink: 703-748 MHz	
	Downlink: 758-803 MHz	

(2) RF Exposure Statements

The antenna of the product, under normal use condition, is at least 20 cm away from the body of user.

(3) Unit Mounting Notice

The product is suitable for mounting at heights <= 2m (approx. 6 ft), or in a cabinet. Ensure the unit is fixed tightly to reduce the likelihood of injury due to exposure to mechanical hazards if dropped.

(4) Manufacturer Information

Manufacturer Name: EtherWAN Systems, Inc.

Manufacturer Address: 8F, No.2, Alley 6, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.)

1.6 Hardware Installation

The following list shows the available hardware ports of the EDGE 2:

- SIM Slot: 1 nano-SIM (4FF)
- Analog Input: 3 AI ports (supports 0-10V / 4-20mA)
- Digital Input: 2 DI ports (isolated, "Logic 0": 0~2V, "Logic 1": 5V~30V; supports Pulse Counter, Dry Contact)
- Digital Output: 1 DO port (isolated, Non-Relayed Output, Maximum 24V/300mA)
- Field Bus: 1 RS-485 for Modbus RTU
- Console Port: 1 Serial TTL UART for device configuration
- Wake-up Port: 1 internal Reed Switch, and 1 dedicated DI for external device wake-up triggering.
- Power Source : 4000mAh 3.6V Li-SOCL2 battery (ER18505, A Size), or external 5V~12V DC power.

This section describes how to install and configure the hardware.

1.6.1 Open the Top Cover

The EDGE 2 is designed for universal data logging use. There are various interfaces for connecting to your field devices, all enclosed with an IP65 grade enclosure. All the connection cables to the field devices must be wired properly through the M16 connectors.

Therefore, prior to connecting and configuring the EDGE 2, you must open the top cover to get access to the control board.

Unscrew the four screws and remove the top cover to the side carefully.



You can see there are many hardware connectors available for you to configure. There are two spring-type terminal blocks, a nano-SIM slot, battery stand, power socket and switch, etc...

Internal View

After removing the top cover, you can see all the available hardware connectors.



Note:

1. By default S1 (Power Switch) is in OFF state, and J6 (Power Source) is in BAT state.

2. Before proceed to the following hardware configuration details, be sure to keep **S1** at **OFF** state till the moment you finish the required configuration and need to power up the device.

3. The **RESET** button provides a quick way to reboot the device.

1.6.2 Insert SIM Card

WARNING: BEFORE INSERTING OR CHANGING THE SIM CARD, PLEASE MAKE SURE THAT POWER TO THE DEVICE IS SWITCHED OFF.

The SIM card slot is located at the upper-right corner of the control board. Please follow the instructions to insert a SIM card (4FF nano-SIM).

Step 1: Follow red arrow to unlock SIM holder.



Step 2:

Lift up SIM holder, and insert 4FF nano-SIM card.



Step 3: Put back SIM holder, and follow red arrow to lock SIM holder.





1.6.3 Install Battery (Optional Accessory)

Step 1: Insert the two cable ties through the battery stands.



Step 2:

Load the battery over the stands as illustrated, and fasten each cable tie tightly.



Step 3:

Cut off the extra cable tie, and plug the power cable onto **CON3** (Battery Power Socket).



WARNING :

- 1. It is strictly forbidden to have the battery positive or negative short circuit, charging, discharging, heated over 100°C, removed, or disassembled. Doing any of these may cause explosion, combustion, internal acid leakage.
- 2. The Li-SOCL2 battery is an one-time use battery. DO NOT re-charge, crush, or disassemble the battery in any situation.
- 3. Discharged batteries are hazardous waste, and should be recycled or brought to a hazardous waste disposal facility.
- 4. Battery Replacement: You can purchase a new (full power) battery and replace it by yourself. The Battery Specification and Power pin must be compliant with the original design:
 - A. 4000mAh 3.6V Li-SOCL2 battery (ER18505, A Size) with power cable.
 - B. Re-use the power connecter: Red pin for V+, and Black pin for GND.
 - C. Follow the Battery Installation procedure mentioned above.

Li-SOCL2 Battery Specification

If you purchase the battery from a 3rd-party, please make sure it complies with the following electrical characteristics. Not only Nominal Capacity and Voltage, but also Max. Continuous Current and Max. Pulse Capacity specifications are important.

ELECTRICAL CHARACTERISTICS

Nominal Capacity 4Ah		
(2mA ,+25 $^\circ\!\mathrm{C}$ 2V cut off.The capacity res	stored by the	
cell varies according to current drain, te	mperature and cut-off)	
Nominal Voltage	3.6V	
Max.Continuous Current	100mA	
Max.Pulse Capability	200mA	
Operating Temperature Range (Operation at temperature different from reduced capacity and lower voltage plat	- 60 ℃ ~+85 ℃ ambient may lead to eau readings)	

1.6.4 Connecting to External Devices

There are many available I/O interfaces for connecting the EDGE 2 data logger to external devices.

As indicated in the I/O pinout sheet, you can easily find out the pin location and connect to your devices with appropriate conductive cables. However, there are only two dual-hole M16 water/dust-proof connectors for you to route the conductive cables out of the enclosure. That is, up to four cables can be routed to connect external devices.

CON1 NC NC NC NC NC NC NC NC NC NC NC NC NC	EN (O) Vcc (BT) GND UART RX (I) UART TX (O) BT State (I) GND VDC ($5V-12V$) VDC ($5V-12V$) VDC ($5V-12V$) GND RS485 D- (A) RS485 D+ (B)	3.6Vout1 GND AI1+ AI1- AI2+ AI2- AI3+ AI3- DO+ DO- DI1+ DI1- GND DI2+	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
	WakeUp +	DI2- GND	15 0 16 0 CON5

In EDGE 2 RJ-45 Model, Pin Assignment is:





M16 - R	1	2	3	4	5	6	7	8
PCB	CON5-3	CON5-4	CON5-9	CON5-10	CON5-11	CON5-12	CON5-14	CON5-15
Name	AI1+	Al1-	DO+	DO-	DI1+	DI1-	DI2+	DI2-
Cable color	White- Orange	Orange	White- Green	Green	Blue	White- Blue	White- Brown	Brown

M16 - L		2	3		5	6		8
PCB	CON2-1	CON2-2	CON2-5	CON2-6	CON5-5	CON5-6	CON2-7 (CON5-7)	CON2-8 (CON5-8)
Name	GND	VDC+	RS485 D-	RS485 D+	Al2+	Al2-	WakeUp - (Al3+)	WakeUp + (Al3-)
Cable color	White- Orange	Orange	White- Green	Green	Blue	White- Blue	White- Brown	Brown

Run External cable to desired connectors:

Step 1: a) Find a conductive cable with 15mm tinned terminals; b) Remove the external part of the M16 connector; c) Run the cable through the external parts as indicated below.



Step 2: a) Place the tinned terminal over the connector; b) Use a flathead screwdriver and push down the clip; c) Insert the tinned terminal to very bottom; d) Release and verify the terminal is well locked.



Screw back the External Parts of M16 Connector:

When you complete all the required hardware and software installation, make sure the device can function as planned. You are ready to lock the cables and external parts of the M16 connectors.

Step 1: a) Just keep required length of cable inside the enclosure; b) Insert the first cable gland part; c) Insert the second cable gland part; d) Insert the stopper if there is spare wire hole. Verify all the insert parts are in position.



Note:

1. Up to two cables can be run through the M16 connector. To ensure the IP65 water/dust-proof performance, all the cable gland parts and also the stopper are required to be installed properly.

2. However, if you intend to run more than two cables through the M16 connector, or if IP65 is not so critical for the installation, you can decide not to put the cable glands, and skip step 1b) ~1d) for more IO flexibility.

Step 2: Place the last insert part of the M16 connector in position and fasten it in a clockwise direction. You have to hold the wire to prevent it twisting while fastening the M16 external part.



Connect to devices via AIs (Analog Input) :

The EDGE 2 provides 3 AI ports for connecting to analog sensor/meters. To connect the device, you have to identify the type of your device and properly connect and configure the EDGE 2 so that it can get the correct readings from the connected devices.

The AI port supports either 0-10V voltage mode, or 4-20mA current mode analog signal. Since the EDGE 2 cannot detect what kind of device it is connected to, not only hardware configuration (**CON4**, **CON5**) is required, but also software configuration is mandatory.

CON4 is dedicated for AI configuration. There are 3 sets of jumper headers, one for each AI port (AI1, AI2, AI3). Without Jumper : **0-10V Voltage mode** - (factory default)

With Jumper : 4-20mA Current mode - (You must put the Jumper manually)

Pinout Definition @ CON5

Pin1*	Pin2	Pin3	Pin4	Pin5	Pin6	Pin7	Pin8
3.6Vout1	GND	Al1+	Al1-	AI2+	AI2-	AI3+	AI3-

Note: 3.6Vout1 @ CON5.1 is only valid when external power source is applied. It is disabled for battery power source.

Analog Input Specification

Mode	Specification				
	Range	Precision			
Voltage Mode	0-10V	+/- 10mV			
Current Mode 4-20mA		+/- 20 μ A			

The EDGE 2 is designed with 10-bit ADCs (Analog-to-Digital Converter), considering hardware scaling and 0.1% resistance variation effects, the overall precision for the 0-10V is around +/-10mV.

If the signal range of your device will run out of the design spec. of the EDGE 2 (0-10V or 4-20mA), you have to add a scaling circuit to prevent overflow readings and even damage to the EDGE 2.

Connect to devices via DIs / DO (Digital Input / Digital Output) :

The EDGE 2 provides 2 DI ports and 1 DO port⁴ for connecting to digital sensor/meter devices. To connect the device, you have to identify the type of device and properly connect and configure the EDGE 2 so that it can get the correct readings from the connected devices.

The DI port supports either Pulse counter mode, or just a Dry contact. Since the EDGE 2 cannot detect what kind of device it is connected to, not only hardware configuration (**CON5**) is required, but also software configuration is mandatory.

Pinout Definition @ CON5

Pin9	Pin10	Pin11	Pin12	Pin13	Pin14	Pin15	Pin16
DO+	DO-	DI1+	DI1-	GND	DI2+	DI2-	GND

Digital I/O Specification

1/0	Specification				
Digital Input	Trigger Voltage (high)	Logic level 1: 5V~30V			
Digital Input	Normal Voltage (low)	Logic level 0: 0V~2V			
Digital Output		Maximum 24V/300mA			
	Non-Relay mode	(Depends on external			
		device)			

Example of Connection Diagram

It is highly recommended to use 5-12 VDC power input instead of battery power if remote control function with Digital output is used for your IOT applications.



Example of Connection Diagram - DO

(1) Sink-type DO Connection





(2) Source-type DO Connection

Connect to Modbus RTU devices via RS-485:

The EDGE 2 provides one RS-485 port and can support up to 8 cascaded Modbus RTU devices. Since the EDGE 2 cannot detect what kind of device it is connected to, not only hardware configuration (**CON2**) is required, but also software configuration is mandatory.

Pinout Definition @ CON2

Pin1	Pin2	Pin3	Pin4	Pin5	Pin6	Pin7	Pin8
GND	VDC (5-12V)	VDC (5-12V)	GND	RS-485 D- (A)	RS-485 D+ (B)	WakeUp-	WakeUp+

Connect to external magnetic switch via WakeUp port:

Most of the time, the EDGE 2 data logger operates under sleep mode with ultra-low power consumption design. At that time, it will not wake up until the scheduled time runs out.

If you still have to wake it up for some unexpected reason, for example, to change software configuration or upgrade new firmware, there is a manual wake-up mechanism for such kind of maintenance situations.

There is an internal magnetic Reed Switch, located at the lower-left corner of the EDGE 2. Just take a small magnet and touch the lower-left corner of the enclosure, the EDGE 2 will detect it and enter into WakeUp state. However, if the EDGE 2 is installed at a hard to reach location or enclosed in a metallic cabinet, there is an alternative option for you to easily wake up the EDGE 2. In such cases, you can connect an external magnetic switch or some kind of switch and connect it to the WakeUp pins. Once the input status changes (OPEN \rightarrow CLOSE), the EDGE 2 will detect it and go into WakeUp state accordingly.

Pinout Definition @ CON2

Pin1	Pin2	Pin3	Pin4	Pin5	Pin6	Pin7	Pin8
GND	VDC (5-12V)	VDC (5-12V)	GND	RS485 D- (A)	RS485 D+ (B)	WakeUp-	WakeUp+

Connect to external DC Power Source:

The EDGE 2 is designed for use with an internal battery power source. This is suitable for infrequent data logging or data uploading applications.

However, there is an alternative external DC Power Source for those applications that require instant or frequent data uploading. Instead of battery power source, you can decide to apply external DC power source to the EDGE 2 directly if there is available DC power source at the installation site.

Pinout Definition @ CON2

Pin1	Pin2	Pin3	Pin4	Pin5	Pin6	Pin7	Pin8
GND	VDC (5-12V)	VDC (5-12V)	GND	RS485 D- (A)	RS485 D+ (B)	WakeUp-	WakeUp+

External DC Power Supply: DC 5-12V Max. Power: 5W @ 5V / 1A

Just connect the external DC Power to Pin1, Pin2 at **CON2**. PIN3, PIN4 are duplicated pins, you can just ignore them.

Additionally, change the power source jumper to the right side (EXT) at J6, as illustrated below.



Note: The EDGE 2 won't go into sleep mode (ultra-low power consumption) when it is powered via external DC power source.

1.6.5 Connecting Console Port for PC Configuration Tool

After completing the prior hardware configuration, you are almost finished with the hardware configuration procedure.

To make the EDGE 2 operate properly in accordance with attached external devices, you have to further configure software settings from a PC configuration tool.

The EDGE 2 provides one serial console port for device configuration. Connect the USB-to-Serial console cable (optional accessory) to the Console Port at **CON1** as illustrated below.



Pinout Definition @ CON1, USB-to-Serial

	Pin1	Pin2	Pin3	Pin4	Pin5	Pin6
CON1 @ EDGE 2	EN (O)	VCC (BT)	GND	UART RX(I)	UART TX(O)	BT State(I)
USB-to-Serial Cable	NC	NC	Black GND	White TX(O)	Green RX(I)	NC



Console port (CON1) with USB-to-Serial Console cable

S3.1 OFF for wired configuration via console cable;

1.6.6 Power On the EDGE 2

Congratulations! You have just finished the required hardware installation procedure, and you are ready to power on the EDGE 2.

Please make sure the power source is properly installed:

For Battery Power: Battery power cable is plugged onto the Power Socket (**CON3**); and Power Source Jumper (**J6**) is placed at the left side (**BAT**).



For External DC Power: External DC power cable is inserted into the external DC Power Ports (**CON2**); and Power Source Jumper (**J6**) is placed at the right side (**EXT**).





Now, just power on the EDGE 2 with Power Switch (S1). Switch it to the left side (ON) and the EDGE 2 is powered on and will start to boot up.





Then you can check the Status LED. It starts with RED light for a few seconds to connect with the LPWA network. After a while, it will turn to BLUE flashing (1 second on, 1 second off) when it is connected to the LPWA network without problem, or you will see the LED flashing (1 second on, 1 second off) with RED light indicating low battery power level or no SIM detected.



@ Power OFF



@ Booted, not connected to LPWA



@ Booted, connected to LPWA

Note: If the Data Logger is powered with battery source, the LED will be forced to OFF state when the device goes into sleep mode.

1.6.7 Setup with Windows-based Configuration Tool

The EDGE 2 must be configured with a Windows configuration tool. Just find a computer with an available USB port, and plug in the USB-to-Serial console cable.

For the first time to set up the EDGE 2 with this Configuration Tool, you must download it, and install it to the local computer with Windows OS for further device configuration.

When you execute the Configuration Tool, you will see the login dialog. Click the drop-down menu next to the "Serial Port". Choose the COM port that is bound to the EDGE 2 console port, and then click the **Connect** button.

🖳 Configuration Tool		_	×
Configuration Tool	Login Serial Port : COM7 Connect Restart	_	×
0EW03F0.K91_m91.0EW0 2020.1023.1200			

Note:

1. Use external DC power source to power on the data logger while configuring via the Windows

Configuration Tool. With DC power source, the device won't go into sleep mode, so you can configure it without time and power consumption considerations.

2. Or, if DC power source is not available at the installation site, it is suggested to **configure the device with a prepared configuration file to prevent unexpected battery power loss**. Restore the prepared configuration file, and quickly edit the settings unique to the certain device

If the connection succeeds, a list of menu items appears on the left side under the Login Tab.

🖳 EtherWAN Edge Series	Configuration Tool	_	×
Login			
Status			
LPWA			
I/O			
Modbus			
Schedule	- Login		
Event			
Server			
LogFormat	Serial Port : COM7 V		
System			
CLI			
	Connect Partet		
	Connect Restart		
0EW03F0.K91_m91.0EW0 2020.1023.1200			

Now that you are logged in to the EDGE 2 console, you can proceed with the required software configuration steps one by one. Refer to the following chapter for details.

1.6.8 Device Mount and Screw Back the Top Cover

After you finished all the software configurations, you are ready to use the EDGE 2 and make it operate as expected. You must take the following actions:

- 1. Power off the EDGE 2, and remove the console cable.
- 2. Mount the EDGE 2 base enclosure on the planned location.
- 3. Make sure all the wiring cables are running in position through the M16 connectors.
- 4. Tightly fasten the external parts on the M16 connectors, holding the internal cables to prevent them from twisting along with the cable gland.
- 5. Power on the EDGE 2, and wait until the Status LED turns BLUE to make sure it is connected to an LPWA network.
- 6. Screw back the top cover with care. Make sure the surrounding rubber pad is fully in position to keep the IP65 performance for water and dust resistance.

Chapter 2 Device Configuration

2.1 Device Status

Click on **Status** menu item, and the EDGE 2 device information and status will display on the configuration area which is located in the right-hand side. If the device status doesn't appear or you want to get the updated status, click the **Status Refresh** button located at the lower right corner to refresh the status immediately.

EtherWAN Edge Series Configuration Tool —									×		
Login	Status										
Status	Device Inform	ation	I / O Connection Status								
LPWA	Model No.	EDGE 2	Analog Input 1	Enable	0-10V	0	.00				
I/O	Serial No.	G18070/105	Analog Input 2	Enable	5 J.J. 4 00 A		00				
Modbus	Senarivo. 0100/04135		Analog input 2	chable	4-20mA 4		.00				
Schedule	Firmware	Firmware 0EW03P0.K91_m91.0EW0_10211700		Disable	0-10V						
Event	LPWA Modem	1	Digital Input 1	Disable	Logical Le	vel					
Server	Model No.	BG96	Digital Input 2	Disable	Logical Le	vel					
LogFormat	IMEI No.	866425039624905	Digital Output	Low							
System	Firmware			Enable	ble RS485						
CLI	- minimule	besonina de la comita de la com	Devee	Enable	110-100						
	Cellular Inform	nation	Power	F (1 P							
	Operator	Chunghwa Telecom	Power Source	External P	ower	_					
	Network Type	CAT-M1	Battery Status	N/A							
		-	Remote Serve	er							
	Freq. Band	3	Server1	hello-test-	plan.azure-	8883					
	Signal Strength	-65 dBm	Server2			1					
	Register Status	Registered	Local Server								
	IP Address	10.197.35.118	Server	Disconneo	ted						
	SIM Status	Ready	System Time								
		-	Device Time	11/16/202	20 11:06:16 A	MM	B	otatus			
2020.1023.1200			Up Time	0000 00:0	8:42			enesii			

You can see the **Device Information** (Device Name, Series No., and Firmware Version), **LPWA Modem** Information (Modem No., IMEI, and Modem Firmware), **Cellular Information** (Operator, Network Type, Freq. Band, Signal Strength, Register Status, IP Address, and SIM Status), **I/O Connection Status** (Analog Input 1~3, Digital Input 1~2, Digital Output and Modbus), **Power** Information (Power Source, and Battery Status), **Remote Server** Settings and **System Time**.

2.2 LPWA Configuration

With SIM card inserted in the SIM socket, you need to enter the required **APN**, optional **Username / Password**, and select the **Network Type** (Cat M1 or NB-IoT) for the LPWA connection. For **Retransmission Type**, you can select Retransmit at next time or No Retransmit. Then click **Save** button to store the settings in the device.

🔡 EtherWAN Edge Series	Configuration Tool				 _	×
Login	LPWA Connecti	on		D. I		
Status				Retransmission Type		
LPWA	APN	internet.iot		Retransmit at next time 🗸 🗸		
I/O	Username (optional)					
Modbus	Password (optional)					
Schedule	, associa (optional)					
Event	Network Type	Cat M1 ∨				
Server						
LogFormat			Save			
System						
CLI						
0EW03F0.K91_m91.0EW0 2020.1023.1200						

These configuration settings shall be provided with the SIM card by the ISP of the LPWA network.

You can check the cellular information on the **Status** page to understand the LPWA connection status. With it, you will know if the SIM card is inserted or not, whether the device is connected to LPWA network or not, and even the LPWA signal strength (-dBm) at the installation site of the data logger.

Cellular Information						
Operator	Chunghwa Telecom					
Network Type	CAT-M1					
Freq. Band	3					
Signal Strength	-65 dBm					
Register Status	Registered					
IP Address	10.198.174.0					
SIM Status	Ready					

At **Retransmission Type** configuration, you can specify the data retransmission behavior if the transferred data failed to reach remote server.

No Retransmit: Drop this failed data, and don't re-sent this log any more.

Retransmit at next time: Keep the transmission failed data, and send it out with new coming data at next scheduled time slot.

Retransmit setup: Specify the retransmit count and time interval. And select the action if it still fails after the specified retransmission session. It can be dropped or retransmit again.

Retransmission Type							
Retransmit at next time 🔹							
No Retransmit							
Retransmit at next time Retransmit setup	•						
Retransmission Type -							
Retransmit setup	•						
Times	3						
Interval(minute)	1						
Determine data at next time if still feil							
Retransmit data at next time if still fail							
Retransmit data at next	time if still fail						

2.3 I/O Configuration

On the I/O Configuration screen, you can configure the Analog Inputs (AIs) and Digital Inputs (DIs). There are 3 sets of AIs and 2 sets of DIs.

🖳 EtherWAN Edge Series	Configurati	on Tool							_		×
Login	Anal	og Input				_ (-Get DataLo	g			
		Al source	Name	Туре	Enable		Times	1	(1-5)	
	•	Analog Input1		0-10V ~	\checkmark		Interval	5	(5-3	0 secon	ids)
Modbus		Analog Input2		4-20mA 🗸	\checkmark					WO I	
Sebedule		Analog Input3		0-10V ~					30	ive	
Schedule	Repo	ort Data Conve	ersion Formu	la							
Event		Al source	(Read Value	Op. XValu	e) Op.	Y Value	Enat	ole			
Server	•	Analog Input1	(Read Value	~) ~]			
LogFormat		Analog Input2	(Read Value	~) ~]			
System		Analog Input3	(Read Value	~) ~]			
CLI	Digit	al Input									
		DI source	Name	Mode	Pulse	e Type	Offset	Enable	e		
	•	Digital Input1		Logical Level	~	~				6.0	
		Digital Input2		Logical Level	~	~				Sa	ve
							-Battery Thr	eshold -			
							Battery Full	3.5	~	V	
							Battery Low	2.7	~	V	
										Save	
0EW03F0.K91_m91.0EW0 2020.1023.1200											

According to the hardware configuration you already finished, you have to further configure the settings for the device firmware, so that the data logger will know what kind of input device is connected to each port.

For analog input ports, you can specify an optional **Name** for identification, and the **type** (**0-10V** or **4-20mA**) for each connected port. Then click **Enable** check boxes for those connected ports.

For report data conversion formula, you can select operation "+" for offset plus or minus adjustment, and "*" for multiplication, like X1000, or X 0.01

For digital input ports, you can specify an optional **Name** for identification, and the **Mode** (*Logical Level*, or *Pulse Counter*) for each connected port. And then click **Enable** check boxes for those connected ports.

If *Pulse Counter* mode is selected, some additional fields (**pulse type** and **Offset** value) have to be defined. **Pulse Type**: It can be **Change**, **Rising**, or **Falling**. On each pulse event, the corresponding internal counter will be increased by 1 automatically.



Offset: Enter the Offset value for initial reading of the connected device (pulse meter). It is very likely that the initial reading for the connected device is a non-zero value, so you have to enter the initial value as an offset for the further readings.

With the settings, the Data Logger will activate 32-bit counters to count the pulse behavior, record the counter value plus the Offset as the actual value on each data logging time slot.

Finally, click the **Save** button to store the configuration in the device. Prior to storing the I/O settings, the following dialog will appear for you to double confirm the settings of Analog Input type that the hardware configuration and software configuration are consistent.

I/O Input		\times
	Please make sure the hardware Jumpers of each Analog Input are manually installed correctly. For 0 - 10V input type, REMOVE the Jumper. For 4 - 20mA input type, ATTACH the Jumper. Otherwise, the input values will be wrong. If you have changed the input type/mode of the Analog/Digital input, you should check and reset the Event Triggers again.	
	<u>Y</u> es <u>N</u> o	

After you confirm the settings are correct, click **Yes** button to store the configuration in the device.

"Get DataLog", this is for error retry times and interval.

For battery power options, there is a Battery Threshold configuration. You can define the Battery Full and Battery Low voltage.



You can check the battery status at the Status Page.

Power	
Power Source	Battery
Battery Status	Full

Full: for voltage >= Battery Full threshold.Good: for voltage between Battery Full and Low thresholds.Low: for voltage <= Battery Low threshold.

The data logger will issue Battery Low event to remote server if it detects the battery voltage approaches the Low threshold. The frequency depends on the Remote Server Schedule rule.

Each time when the data logger is woken up to send the stored log to remote server, if the Battery Low threshold is triggered, the data logger will automatically issue a Battery Low event.

So, when the administrator notices that Battery Low events are issued, he should dispatch battery replacement task prior to the data logger using up the battery power and failing to operate properly.

2.4 Modbus Configuration

The EDGE 2 provides one RS-485 port for connecting with Modbus RTU Slave devices. It can handle up to eight sets of cascaded Modbus devices.

🖳 EtherWAN Edge Series (Configuration Tool								- 🗆	×
Login	RS-485						- Get Da	taLog		
LPWA	Interface	Enable	~	Stop Bits	1	~	Times	1	(1-5)	
I/O	Baud Rate	9600	~	Parity	None	~	Interva	I 5	(5-30 se	conds)
Modbus	Data Bits	8	~						Save	
Schedule										
Event	Modbus Do	ico 🗌	Add							
Server	Modbus Dev	NCe	Add							
LogFormat	Name	Slave ID	Fun	ction Code	Start Address	No. of Coils/	Registers	Edit	Delete	
System	Temp+Humidi 4	1	3		0	2		Edit	Dele	te
CLI	PM10 5	5	3		1	1		Edit	Dele	te
0EW03P0.K91_m91.0EW0 2020.1023.1200									Sa	ve

RS-485 Serial Port Configuration

Prior to configuring how to access the Modbus devices, you need to define the physical communication port first. In RS-485 configuration, you can enable the **Interface**, and then select desired values for **Baud Rate**, **Data Bits**, **Stop Bits**, and **Parity** settings.

- **Interface**: By default, the interface is disabled. You can enable it and set the interface parameter to comply with the devices to be connected.
- Baud Rate: Select the appropriate baud rate for serial device communication. It can be 1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200. It depends on the cable length and the installed environment. The longer cable length will result in lower baud rate for it. By default, 9600 is selected.

Data Bits: Select 7 or 8 for data bits. 8 is selected by default.

Stop Bits: Select 1 or 2 for data bits. 1 is selected by default.

Parity: Select None / Even / Odd for Parity bit. None is selected by default.

Modbus Device Configuration

Click Add button to enter required information or values for each Modbus device. The data fields are Name, Slave ID, Function Code, Start Address, and No. of Coils/Registers. When you entered the required settings for a Modbus device, click Confirm button to update the information to the device list. In addition, you can also click Edit or Delete button to modify the information or values in the device list.

Modbus De	evice Ad	d				
Name	Slave ID	Function Code	Start Address	No. of Coils/Registers	Edit	Delete
т	4	3	0	1	Edit	Delete
н	4	3	1	1	Edit	Delete
Name			Func	tion Code Re	ad Holding Regis	ters (0x03) 🗸
Slave ID)	(1-247)	Start	Address		(0-65535)
			No. of Coils/Registers			(1-125)
					Confirm	Cancel
						Save

Name: Enter a name as the identifier of the Modbus RTU slave device.

Slave ID: Specify a unique ID for the slave device. It can be 1 - 247.

Function Code: Specify a certain read function for the Data Logger to issue and record the responses from slave device. It can be Read Coils (0x01), Read Discrete Input (0x02), Read Holding Registers (0x03), and Read Input Registers (0x04).

- Start Address: Enter the Start Address of registers to apply with the specified function code. It can be 0 65535.
- No. of Coils/Registers: Enter the number of coils (registers) to apply with the specified function code. It can be 1 125.

Check the documentation for the connected Modbus devices on how to get the desired data through Modbus commands.

Finally, click **Save** button to store the configuration in the device.

Moreover, you can specify the behavior of data logging from the Get DataLog window. Once the scheduled time is up, the Data Logger will get and log all the Modbus RTU values.

Get DataLog								
Times	1	(1-5)						
Interval	5	(5-30 seconds)						
		Save						

Times: Specify the data logging counts for each schedule time up. **Interval**: Specify the time interval between two data logging.

2.5 Schedule Configuration

The major function of the EDGE 2 Data Logger is to record the status of connected devices at pre-defined time intervals, and upload the stored data logs to remote server at another designated time interval. All these actions are guided by a set of schedule rules.

In the **Schedule** Configuration page, you have to define the required schedule rules for the application being deployed. For example, record the status of AI / DI ports once per hour, record the status of Modbus devices once per day, and upload the pending logs to remote server on every Monday 02:00a.m..

The EDGE 2 Data Logger provides different types of time options for defining the time interval or frequency as time schedule. Set up your planned schedule and the Data Logger will take appropriate action accordingly by the schedule rule.

💀 EtherWAN Edge Series (Configuration To	ol								- 🗆	×
Login	Schodulo		dd								
Status	Schedule		luu								1
LPWA	Name	Mode	Туре	Month	Date	Week	Hour	Minute	Interval	I/O	
I/O	sch1	Static	Per Seco						60		-
Modbus	sch2	Static	Per Minu				0	0	5		
Schedule											
Event											
Server											
LogFormat											
System	<									>	
CLI											
0EW03P0.K91_m91.0EW0										Save	

Click the **Add** button to enter required settings for a new schedule rule. The data fields are **Name**, **Mode**, **Type**, **Time** (Month, Date, Week, Hour, Minute, and Interval), **I/O**, **Modbus**, **Remote Server**, **Remote Control** and **Remote Boot**. When you have entered the required settings, click **Confirm** button to update the information to the rule list. In addition, you can also click **Edit** or **Delete** button to modify the settings in the rule list.

Schedule Name	Time		-Function
	Month	1 ~	□ I/O
Schedule Mode	Date	~	Modbus Remote Server
Schedule Type	Week		
Yearly O Per Seconds	Hour	~	
 Monthly Per Minutes Weekly Per Hours 	Minute	~	
 Daily Per Days Hourly 	Start	(hour:min)	
 Minutely 	Interval		Confirm Cancel
			Save

Name:	Specify a name as the identifier of the Modbus RTU slave device.
-------	--

- Mode: Static is for pure time scheduled driven Function list; Triggered is for condition driven Function list, there are 2 conditions triggered from, (1) "System" page select "Wake-up Triggered" set Alert to "Data Action" and (2) "Event" page check "Trigger Schedule". Once conditions (1) or (2) are satisfied, it will drive Function list.
- Type:Select the schedule type for the data logger to take action. There are two groups of types
for your preference.

Group 1 consists of **Yearly**, **Monthly**, **Weekly**, **Daily**, **Hourly** and **Minutely**. You select a time period, and the data logger will be triggered once to take function action (data logging, or uploading) for each selected period.

Group 2 consists of **per Seconds**, **per Minutes**, **per Hours**, and **per Days**. You select a time base, and the data logger will be triggered on each expected time interval to take function action (data logging, or uploading).

- Time:In conjunction with the schedule type you selected, you have to further specify a precise
time (date, and/or time), or a time interval for the time scheduler to count the time.
- Function: Click on the checkbox to select expected action(s) to take for the schedule rule. It can be I/O, and/or Modbus for a data logging rule; Remote Server for a data uploading rule; Remote Control to enable downlink control once asleep, and Reboot for scheduled reboot of device.

Finally, click **Save** button to store the configuration in the device.

Hereunder are more description and examples for the different schedule types:

Yearly Triggered at a fixed time in each year. For example, when Month=1, Date=1, Hour=1, Minute=1, the schedule rule will be triggered at 1/1 01:01 every year.

- **Monthly** Triggered at a fixed time in each month. For example, when Date=1, Hour=1, Minute=1, the schedule rule will be triggered at 01:01 on the 1st day in every month.
- **Weekly** Triggered at a fixed time in each week. For example, when Week=Sun, Hour=1, Minute=1, the schedule rule will be triggered at 01:01 every Sunday.
- **Daily** Triggered at a fixed time in a day. For example, when Hour=1, Minute=1, the schedule rule will be triggered at 01:01 every day.
- **Hourly** Triggered at a fixed time in an hour. For example, when Minute=15, the schedule rule will be triggered at the 15th minute every hour.
- Per Triggered at a fixed interval per minutes. For example, when Start=12:00, Interval=5, the scheduled
 Minutes function will start at 12:05, 12:10, 12:15, and so on. The minimum interval of "Per Minutes" to place is 5 and the maximum is 7200.
- PerTriggered at a fixed interval per hours. For example, when Start =12:00, Interval =2, the scheduledHoursfunction will start at 14:00, 16:00, 18:00, and so on. The minimum interval of "Per Hours" to place is
1 and the maximum is 23.
- **Per Days** Triggered at a fixed interval per days. For example, when Start=12:00, Interval=1, the scheduled function will start at 01/01 12:00, 01/02 12:00, 01/03 12:00, and so on. The minimum interval of "Per Days" to place is **1** and the maximum is **6**.

2.6 Event Configuration

The Event Trigger function can use a certain input signal (device) as trigger source for an event rule. If there is an enabled event rule, the data logger will check the trigger source once per second to determine if event is triggered. When the designated condition matches, the event rule will be triggered and corresponding event action will take place accordingly.

The data logger supports up to 8 event rules. Click the **Edit** button to edit a specific event trigger. For each event rule (If *condition* then *action*), you have to specify the condition part, Condition Holding time, and the action part.

Condition part: (condition 1) AND / OR (condition 2)

Condition Holding Time: Above *Condition* remains **TRUE** for at least *T*_{hold} (condition hold time) in second. Action part: make **DO High**, **DO Low**, or set **Trigger Schedule event flag** till the condition is **FALSE**

🛃 EtherWAN Edge Series C	Configuration Too	I									_		×
Login	Event Tria	nor										6	
Status	Eventing	gei											
LPWA	Trigger	Name	Cond.	Value 1	Op.	Cond.	Value 2	Condition Holding	DO High	DO	Trigger	Enable	Edit
I/O	Source		-			-		Time	ingi	LOW	Schedule		
Modbus	MODBUS1	T-High	> =	2500				0	\square				Edit
Schedule	MODBUS1	T-Low	< =	2000				0		\checkmark			Edit
Event			>	0				0					Edit
Server			=	0				0					Edit
LogFormat			=	0				0					Edit
System			=	0				0					Edit
CLI			=	0				0					Edit
			=	0				0					Edit
			Action part										
									_				
0EW03P0.K91_m91.0EW0 2020.1023.1200												Save	

Name: Specify a name as the identifier of the event rule.

Trigger Source: Available trigger source can be **AI**s, **DI**s, and **Modbus**. You can select one of them as the event trigger source.

Cond.1/2: Up to two conditions can be defined in an event rule. For each condition, five comparison operators. ">",">=","=","<" and "<=" can be selected. Select an operator and enter a threshold value for comparison.

Value1/2:	Enter the threshold value in decimal number of condition 1/2 for comparison.
Operation :	If cond.2 exists, specify the logic operation (AND, OR) for cond.1 and cond.2.
Condition H	old Time: Enter a time interval as the threshold of required minimum condition hold time
	(<i>T_{hold}</i>)in second. The condition must remain TRUE for at least the specified duration.
Action:	The supported event action can be DO High , DO Low or Trigger Schedule which is related
	to "Schedule mode" in Schedule setting. Select one action for each event rule. When the
	event happens (condition TRUE for the T_{hold} duration), the specified action will be taken
	accordingly.
Enable:	Check Enable to activate the event rule.

Finally, click **Save** button to store the configuration in the device.

Warning:

It is NOT recommended to use battery power to power the EDGE 2 while the event trigger function is used for your deployed application. The data logger will be wake up once per second to check if there is any event to be triggered. It is a power consuming operation.

So, EXTERNAL DC POWER SOURCE IS RECOMMENDED! Otherwise, you will suffer from short battery life problem, and have to pay higher overhead costs for new batteries.

2.7 Server Configuration

The EDGE 2 Data Logger is designed to collect field device status / readings, store in embedded non-volatile memory in according to the specified time period, and then upload the collected data to remote server, via LPWA connection, for further processing and analysis by schedule.

So, you have to specify where the remote server is, and how to communicate with the server. The EDGE 2 supports two sets of remote servers, and three protocols (UDP, TCP, and MQTT) for communicating with the server(s).

There are some situations that the administrator at remote control center would like to send commands to the Data Logger for specific actions. The Data Logger provides such downlink communication, realized with MQTT subscription. You can specify a MQTT server (Broker) and the message topic to subscribe.

Once the Data logger is woken up on remote server schedule rule, it will get the pending commands queued in the server, and then take the corresponding action consequently.

Remote Server Configuration

The Data Logger packs the logged data with specified protocol with required packet headers, and then sends out complete packets to remote server. To retrieve the data logs sent to remote server, the server has to run a simple daemon to collect the packets sent from deployed data loggers, and interpret the data fields for mapping to each field device.

🛃 EtherWAN Edge Series	Configuration Tool					_	
Login	Remote Server Local	Server Certificate					
Status	Server 1			Server 2			
LPWA	Protocol	MQTT ~		Protocol	UDP	~	
I/O	Server IP / FQDN	UDP		Server IP / FQDN			
Modbus	Port(1~65535)	MQTT	Save	Port(1~65535)	1		Save
Schedule							
Event							
Server							
LogFormat							
System							
0EW03F0.K91_m91.0EW0 2020.1023.1200							

To finish the Server Configuration, you have to specify the following settings:

 Protocol: Select a communication protocol for the drop down list. It can be UDP, TCP or MQTT.
 Server IP/FQDN: Enter the global IP address or FQDN of the remote server, or MQTT broker. Leave it as blank to disable the corresponding server settings. It is set as blank by default.
 Port (1~65535): Enter the port number used to communicate with deployed Data Loggers.

Finally, click **Save** button to store the configuration in the device.

Additional MQTT Settings

When **MQTT** protocol is selected, for Generic Broker, additional settings will appear on the screen. Enter the required information for **Username**, **Password**, **Client ID**, **Event Topic**, and **Data Topic**, set the **QoS Level** and **Retain** settings.

🛃 EtherWAN Edge Series	Configuration Tool						_	
Login	Remote Server Local	Server Certificate						
Status	Server 1				Server 2			
LPWA	Protocol	MQTT	-		Protocol	UDP	~	
I/O	Server	Generic Broker	-		Server IP / FQDN			
Modbus	IP / FQDN	test.mosquitto.org			Port(1~65535)	1		Save
Schedule	Port(1~65535)	1883	_					
Event	_ MQTT		_ 1					
Server	Username							
LogFormat	Password							
System	Security	None ~						
CLI	CA File		,					
	Certificate File							
	Key File							
	Client ID	etherwan_edge2						
	QoS Level	0(At most once) ~	•					
	Retain	No	·					
	Event Topic	EWEVENT	1					
0EW03P0.K91_m91.0EW0 2020.1023.1200	Data Topic	EWEDGE		Save				

Username: Password: Security:	Enter optional username (account) given by MQTT Broker, if authentication is required. Enter optional password given by MQTT Broker, if authentication is required. Select None or SSL , which related files can add from Certificate Configuration
Client ID:	Specify a unique ID for the data logger. It can be the Serial No. of the data logger. The default ID is set to the device Serial No.
QoS Level:	Select the QoS type for publishing a message. For the LPWA data logger, 0 (At most once) is preferred to keep its low power consumption performance.
	0 (At most once) : the message will be published only once, and the broker and subscribed client(s) take no additional steps to acknowledge the develivery.
	1 (At least once) : the message will be published at least once until acknowledgement is received from the broker or subscribed client(s).
	2 (Exactly once) : the message will be published to subscriber(s) once in a two-level handshake to ensure only one copy of the message is received.
Retain:	Select the Retain policy, Yes or No , for publishing a message. By default, No is selected.
Event Topic	: Specify the topic name for the system-related message. The messages for LPWA status and
	Battery Low belong to the event message, and are helpful for device management.
Data Topic:	Specify the topic name for the data logging message. The messages for AI/DI data and
	Modbus data belong to this topic. Up to 64 characters for the topic name.

Event and Data topics provide a simple way for message classification. However, you can also decide to specify the same name for both topics.

Additional Azure IoT Settings

When **MQTT** protocol is selected for Azure IoT. Enter the required information **Connection String** settings.

🖳 EtherWAN Edge Series	Configuration Tool				_	
Login	Remote Server Local S	erver Certificate				
Status	Server 1		Server 2			
LPWA	Protocol	MQTT ~	Protocol	UDP	~	
I/O	Server	Azure IoT ~	Server IP / FQDN			
Modbus	Connect String	HostName=hello-test-plan.azure-	Port(1~65535)	1		Save
Schedule	, second s	devices.net;DeviceId=el_edge2;Share	Pon(1=00000)	-		Save
Event		dAccessivey=D34ti				
Server						
LogFormat						
System						
СЦ						
OPUTORED KOLOI OPUTO		Salve				
2020.1023.1200		Save				

Local Server Configuration

You can activate the Local Server function to get the downlink commands and take corresponding actions. Currently, **OTA FW Upgrade**, **DO Control** and **Modbus Control** are supported. You can select the command type and then configure the details.

💀 EtherWAN Edge Series	Configuration Tool						×
Login	Remote Server	Local Server Certifica	ate				
Status		Remote Control					
LPWA		Kemote Control	<u> </u>				
I/O		Protocol	MQTT	~	DO On/Off		
Modbus		Server	Generic Broker	\sim	Modbus Control		
Schedule		IP / FQDN	test.mosquitto.org				
Event		Port(1~65535)	1883				
Server		-MQTT Subscribe)				
LogFormat		Username					
System		Password					
CLI		Security	None	~			
		CA File					
		Certificate File					
		Key File					
		Client ID	etherwan_edge2				
		QoS Level	0(At most once)	~			
		Topic	EWDO				
0EW03F0.K91_m91.0EW0 2020.1023.1200		Group Topic			Save		

First, select the command type, and then configure the MQTT-related settings (Server IP/FQDN, Port, Username, Password, Client ID, QoS Level and Topic).

Server IP/FQDN: Enter the global IP address or FQDN of the MQTT server or MQTT broker. It is set as blank by default.

- **Port (1~65535):** Enter the port number used by the MQTT server.
- **Username**: Enter optional username (account) given by MQTT Broker, if authentication is required.
- **Password**: Enter optional password given by MQTT Broker, if authentication is required.
- **Client ID:** Specify a unique ID for the data logger. It can be the Serial No. of the data logger. The default ID is set to the device Serial No.
- **QoS Level:** Select the QoS type for publishing a message. For the downlink communication with LPWA data logger, 2 (Exactly once) is preferred to make sure the data loggers won't miss the commands issued from remote control center.

0 (At most once): the message will be published only once, and the broker and subscribed client(s) take no additional steps to acknowledge the develovery.

1 (At least once): the message will be published at least once until acknowledgement is received from the broker or subscribed client(s).

2 (Exactly once): the message will be published to subscriber(s) once in a two-level handshake to ensure only one copy of the message is received.

Topic : Specify the topic name for the corresponding downlink command. The messages for LPWA status and Battery Low belong to the event message, and are helpful for device management.
 For example, *FW_OTA* as the topic of OTA FW Upgrade command, *DO_Setting* as the topic of DO control command and *Modbus Control* refer to Modbus downlink control for function code 5 and 6.

As to the details about command format, refer to Section 3.2 Downlink Command Format.

Certificate Configuration

This can add SSL related files when Security of MQTT welect SSL.

Login Remote Server Local Server Certificate Status I/O Modbus Schedule Event Server LogFormat System CLI Name: Browse Add Delete Refresh 0%	therWAN Edge Series	Configuration Tool						_
Status LPWA NO Modbus Schedule Event Server LogFormat System CLI Name: Browse Add Delete Refresh 0%	Login	Remote Server	Local Server	Certificate				
LPWA I/O Modbus Schedule Event Server LogFormat System CLI Name: Browse Add Delete Refresh 0%	Status							
I/O Modbus Schedule Event Server LogFormat System CLI Name: Browse Add Delete Refresh 0%	LPWA	File						
Modbus Schedule Event Server LogFormat System CLI Name: Browse Add Delete Refresh 0%	I/O	ca.crt						
Schedule Event Server LogFormat System CLI Name: Browse Add Delete Refresh 0%	Modbus							
Event Server LogFormat System CLI Name: Browse Add Delete Refresh U	Schedule							
Server LogFormat System CLI Name: Browse Add Delete Refresh	Event							
LogFormat System CLI Name: Browse Add Delete Refresh	Server							
System Image: CLI Name: Image: Im	LogFormat							
CLI Name: Browse Add Delete Refresh	System							
Browse Add Delete Refresh 0%	CLI	Name:						
0%			Browse	Add	Delete	Refresh		
						0%		

2.8 Log Format

The EDGE 2 Data Logger is designed to collect field data and send to remote server. There are two types of log format for user to define as needed, the only difference is the sending of the latest messages (Manual) or including history field data (Default), once the scheduled time trigger sends data to a remote server.

LogFormat: There are 2 types:

Default – it is time base to send message data in time stamp with history to remote server until all data in log is sent out. For detailed description, please refer to chapter 3.1.

Manual - Customize field data for any combination of <u>constant name</u> (English Letters and Numbers), <u>symbol</u> (like {}[],:) and <u>variables</u> which are raw filed data content and leading with "\$" to identify. For example, user can design for JSON format for needs.



EtherWAN Edge Series (Configuration Tool									
										~
Status	LogFormat M	Aanual ∽								
LPWA	Evampla	Annual	Cat							
		vianuai 🗸 🗸	Set							
Modbus	{Time:\$t\$,Device	SN:\$id\$,RSSI:\$rssi	\$,\$jdy\$:{Ten	np:\$m1_val\$,\$m	1_name\$:\$m1_val\$,	,AI-1:\$ai1\$mv,	,AI-2:\$ai2\$	mA}}	
Schedule	Ex: [{id: \$ai1_na	ame\$, val: \$ai1_val\$	},{id: \$di1_n	ame\$, val: \$di1_	val\$},{id:	\$m1_name	e\$, val: \$m1_va	al\$}]		
Event	Data Mapping	Add								
Server	Format Symbol	Format dat	а	User-defined [Data	Edit	Delete			
LogFormat	jdy	Manual		JERRY		Edit	Delete			
System	t	Timestamp				Edit	Delete			
CLI	m1_val	Modbus1 V	Modbus1 Value			Edit	Delete			
	m1_name	Modbus1 N	lame			Edit	Delete			
	rssi	Signal Stre	ngth			Edit	Delete			
	id	Serial Num	ber			Edit	Delete			
	ail	Al1 Value				Edit	Delete			
	ai2	AI2 Value				Edit	Delete			
								I		
	Format Symbo	ol Format Data	a							
	m1_name	Modbus1 N	lame ~		Confirm	n				
					Cancel					
0EW03F0.K91_w91.0EW0 2020.1023.1200									Save	

🖳 EtherWAN Edge Series C	onfiguration Tool		AI2 Value						-	_		×
Lania			AI3 Name									
Login			AI3 Value									
Status	LogFormat	Manual	DI1 Name									
LPWA	Example	Manual	DI2 Name									
I/O	· · · · ·		DI2 Value									
Man dibuur	{Time:\$t\$,Dev	iceSN:\$id	Modbus1 Name		p:\$m1_val\$,\$m1	L_name\$	\$m1_val\$	Al-1:\$ai1\$mv,	,AI-2:\$ai2	\$mA	}}	
MODUS	Ex: [{id: \$ai1	_name\$, v	Modbus1 Value		me\$, val: \$di1_v	/al\$},{id:	\$m1_nam	e\$, val: \$m1_v	al\$}]			
Schedule	Data Manni		Modbus2 Name									
Event		ng 🏼 🌾	Modbus2 Value						_			
Server	Format Symb	ol	Modbus3 Name		User-defined Da	ata	Edit	Delete				
Joint Cit	jdy		Modbus4 Name		JERRY		Edit	Delete				
LogFormat	t		Modbus4 Value				Edit	Delete				
System			Modbus5 Name				E dite	Delete				
CLI	m1_vai		Modbus5 Value				Edit	Delete				
	m1_name		Modbus6 Name				Edit	Delete				
	rssi		Modbus6 Value Modbus7 Name				Edit	Delete				
	id		Modbus7 Value				Edit	Delete				
	ail		Modbus8 Name				Edit	Delete				
	ai2		Timestamp				Edit	Delete				
			Serial Number									
			Signal Strength									
	Format Syn	nbol	Battery Voltage	~								
	m1_name		Modbus1 Name	~		Confirm	1					
						Cancel						
0EW03F0.K91_m91.0EW0 2020.1023.1200										Sa	ave	

2.9 System Configuration

System Configuration allows the device administrator / installer to manage the Data Logger. There are settings / function buttons for **Reboot**, **Reset to Default**, **Configuration Backup / Restore**, **System Log**, **Firmware Upgrade**, **System Time**, **Wake-up Trigger**, **Sleep Mode** and **Language**.

🖳 EtherWAN Edge Series	Configuration Tool		- 🗆 X
Login Status LPWA I/O Modbus Schedule	Reboot Reboot Configuration Bac Backup System Log	Reset to Default Reset kup / Restore Restore	System Time Sync. Time with your PC Sync. Sync. Time with LPWA Network Time Service Sync.
Event Server LogFormat System CLI	Download Firmware Upgrad File Name:	e	Set System Time Manually 12/11/2020 V 6:06:37 PM 🛨 Set
	Upgrade	0% Upgrade	Wake-up Trigger Alert Trigger Schedule V Save
0EW03F0.K91_w91.0EW0 2020.1023.1200			Auto Save Language English .

Reboot or Reset to Default

For some special reason or situation, you may need to reboot the Data Logger or reset the device configuration to its default value.

Click Reboot or Reset button, and wait a while for the device to reboot.

Configuration Backup / Restore

In addition to the factory default settings, you can also customize a special configuration setting as a customized default value. With this customized default value, you can reset the device to the expected default setting if needed.

Click Backup button to store the device configuration settings into a configuration file (.bin) for later use.

Click **Restore** button to restore the device settings to a certain backup copy, or quickly duplicate a device's configuration file to other devices with the same configuration for a certain application. In such case, be sure to set the unique Device ID for separate devices.

System Log

For some device maintenance purposes, you may need to get the system log for troubleshooting. You can do it through the configuration tool, click **Download Log** or **Delete** button.

Click **Download Log** button to store the System Log into a log file (.txt) for troubleshooting.

Click **Delete** button to erase the existing system logs. Please use the delete function with care, all the device system log, including data log, will be erased. If required, download log first and then delete out-of-date log.

Firmware Upgrade

If new firmware is available, you can manually upgrade it for feature enhancement or bug resolving.

Click **Open** button to identify the file location / file name of the new firmware image (.bin).

Click **Upgrade** button to start upgrading the new firmware to the device. DO NOT turn off the Data Logger, or disconnect the console cable while upgrading new firmware, it is very likely to damage the device.

Once the Firmware Upgrade is completed, the device will be reboot with the new firmware immediately.

System Time

System time is a vital element for the Data Logger. Both data logging and data uploading tasks need to be triggered at a certain time. You have to make sure the Data Logger is configured with correct time settings.

There are three approaches for initial settings. You can simply click **Sync** button to synchronize the Data Logger's time with your PC that is running the configuration tool, or synchronize it with the LPWA network time service. You can also set the date and time for the Data Logger manually.

Wake-Up Trigger

Most of the time, the EDGE 2 data logger operates under sleep mode with ultra-low power consumption design. At that time, it will not wake until the scheduled time.

However, there is a manual Wake-Up Trigger mechanism for you to wake up the data logger for some unexpected reason, for example, to change software configuration or upgrade firmware.

Below is for software Alert function setting and sleep

There are 3 settings in alert:

Disable: Disable wake up trigger function

Trigger Schedule: By **Schedule** setting, schedule trigger to send field data and schedule trigger to read field data.

Data Action: Once WakeUp pin is short, it triggers continued field data reading and sending of field data content to remote server until WakeUp pin is open.

Sleep Mode

By default, the Reed Switch Wake-Up Trigger is enabled. The Reed Switch is located at the lower-left corner of the EDGE 2. You can just take a small magnet and touch the lower-left corner of the enclosure, the device will detect it and enter WakeUp state. You can also do this by short WakeUp + and WakeUp – on CON 2.

Sleep mode is designed for power saving when device is powered by battery. Once it is connected to external power, the device is always on.

Auto: Always wake up when connected to external power. If connected to battery power, schedule awake to operate or short WakeUp pin or Reed Switch Wake Up trigger.

Manual with **Enable**: For both external power and battery power, device is always in scheduled awake. **Manual** with **Disable**: For both external power and battery power, device is always up.

Language

Supports English and Japanese.

2.10 CLI

CLI allows user to observe message flow in device.



Chapter 3 Data and Command Formats

According to the defined schedule rules, the Data Logger will log the status of the connected devices (AIs, DIs, and Modbus) in non-volatile storage, and upload those pending logs to specified remote server(s).

When the remote server (UDP / TCP / MQTT protocols) receives the packets of data logs, it can easily get the payload, interpret the data fields, and then import the data to the application database for further processing.

The administrator can issue downlink commands via MQTT message from the control center for controlling the deployed data loggers. For example, OTA firmware upgrade, or change DO status to turn ON/OFF for a specific connected device.

3.1 Data Log Format

Each data log entry is composed with a formatted string, followed with CR / LF characters.

SerialNo DateTime LogType:Data

SerialNo :	Serial no. for the device that sent the data log.		
DateTime:	The recorded time for the following data log.		
LogType:	The type of the following data. It can be IO, M1, M2, and M3. Each log type will be		
	follow with different data format.		
	There are some non-data LogType event logs for management purposes. It can be EB		
	(Battery Low), EN (Uplink Network), EP (Power ON), and EW (Device WakeUp).		
Data:	The actual data for the corresponding type of device.		

Data Format of IO:

IO:TypeVal1,TypeVal2,TypeVal3,TypeVal4,TypeVal5

The Data Logger provides five Input ports. Each time the IO schedule rule triggered, the port type and status for all the five ports will be recorded as the data log simultaneously in an IO record.

TypeVal1~5 :One character for the type, V for 0-10V Voltage mode; A for 4-20mA Current mode; D
for Dry Contact; and P for Pulse Counter.
Followed by a value for each port.
A certain TypeVal will be skipped if it is a disabled port.

For examples,

"IO:V1.10,A12.50,V3.30,D1,P1234" stands for a log entry from Input ports, where Port A1 is 1.10Volt, A2 is

12.50mA, AI3 is 3.3Volt, D1 is at '1' for HIGH, D2 counter reading is 1234.

"*IO:V1.10,,,D0,*" stands for a log entry from Input ports, where Port A1 is 1.10Volt, D1 is at '0' for LOW. In this case, AI2, AI3, and D2 are missing because they are disabled.

Data Format of M1, M2, M3, M4, M5, M6, M7, M8:

M1:ID,FC,ADDR,LEN:Val M2:ID,FC,ADDR,LEN:Val M3:ID,FC,ADDR,LEN:Val

The Data Logger supports up to three Modbus RTU devices. Each time the Modbus schedule rule triggered, the specified device status will be recorded as the data log in individual M1/M2/M3 record sequentially.

ID :The Modbus ID for the corresponding Modus device.FC :The function code issued to get the Modbus data.ADDR :The start address for getting the Modbus data.LEN :The no. of coils/registers for getting the Modbus data.Val :The recorded Modbus data that is retrieved with specified command.

For example,

"*M1:1,1,0,32:01020304*" stands for it is a log entry from the first Modbus device, where Modbus ID is 1, Function Code is 1, Start address is 0, no. of Coils is 32(bits), data string is 01020304.

"M2:2,2,1,1:00" stands for it is a log entry from the second Modbus device, where Modbus ID is 2, Function Code is 2, Start address is 1, no. of Coils is 1(bit), data string is 00.

"M3:10,3,2,3:010102020303" stands for a log entry from the second Modbus device, where Modbus ID is 10, Function Code is 2, Start address is 2, no. of Registers is 3(word), data string is 010102020303.

Data Format of EB, EN, EP, EW:

EB:battery_voltage
EN:band,signal
EP:
EW:

For device management purpose, the Data Logger will also record some important device activities as event logs, and uploading to remote server in according to the schedule rule. The types of event logs can be **EB** (Battery Low event with voltage reading), **EN** (Uplink Connection event with band number and signal strength in use), **EP** (Power ON event for alerting when the device is powered on), and **EW** (Device WakeUp for alerting when the device is waked up via external trigger).

3.2 Downlink Command Format

When you want to issue a downlink command from the remote control center to the deployed data loggers, you have to prepared a MQTT message based on the downlink command format. So that, the data logger can recognize and take the expected action accordingly.

Command Format of OTA FW Upgrade:

FWUpg=type;FWVer=Xaa_Ybb;FWPATH=http://file_path

The Data Logger supports OTA FW upgrade. It can be triggered via a OTA FW upgrade command via MQTT message. In the MQTT message payload, you have to specify the required information as above format.

type :Specify the type of OTA FW Upgrade. Currently, only type 1 is available.

1: force upgrade, ignore the version check.

2: new version replacement, version check is required. If the OTA FW version is newer

or greater than that of the existing firmware, the data logger will try to get the FW and

upgrade with it.Xaa_ybb:Specify the FW version of OTA firmware.

file_path:File_path:Specify the file path (URL) of OTA firmware file. Once the data logger received the OTA

FW Upgrade command, it will get the upgrade file from designated file path and then

upgrade it on the device.

Command Format of DO Control:

DO=x;SN=serial_no

The Data Logger supports DO (Digital Output) Control via MQTT message. In the MQTT message payload, you have to specify the required information as above format.

x :	Specify the DO status.		
	'O' : for OFF (output low)		
	'1' : for ON (output high)		
Serial_no :	Serial no. of the target device.		
	It can be blank for non-specific target devices that get the command.		

For example,

"DO=0" stands for all the device received this command is asked to set the DO signal to low level.

"DO=1;SN=ZZ12345678" stands for the device whose serial no is ZZ12345678 is asked to set the DO signal to high level.

Command Format of Modbus Control (Write):

Modbus=Slave ID(1 byte)Function code(1 byte)Start Address(2 bytes Big Endian)Data Length(2 bytes Big Endian)Data Content(max 256 bytes)

This supports Modbus Control via MQTT message. In the MQTT message payload, you have to specify the required information as above format.

Only for Write function code.

Data Length: Total data content to write (bytes).

(Function 0x05 force set single coil. Byte Data count: 1, value range: 0x00 ~ 0x01)

(Function 0x06 force set single register. Byte Data count: 2, value range: 0x0000 ~ 0xFFFF)

For example,

Modbus=0105000000101 Modbus=01060000002ABCD Modbus=0a06000100027788;SN=ZZ12345678

Contact Information

EtherWAN System, Inc.

www.etherwan.com

.....

USA Office

2301 E. Winston Road Anaheim, CA 9280 Tel: +1-714-779-3800 Email: info@etherwan.com

Pacific Rim Office

8F., No.2, Alley 6, Lane 235, Baoqiao Rd. Xindian District, New Taipei City 231 Taiwan Tel: +886 -2- 6629-8986 Email: info@etherwan.com.tw

.....

EtherWAN has made a good faith effort to ensure the accuracy of the information in this document and disclaims the implied warranties of merchantability and fitness for a particular purpose, and makes no express warranties, except as may be stated in its written agreement with and for its customers.

EtherWAN shall not be held liable to anyone for any indirect, special or consequential damages due to omissions or errors. The information and specifications in this document are subject to change without notice.

Copyright 2021. All Rights Reserved.

All trademarks and registered trademarks are the property of their respective owners

February 8, 2021