



**eLite Network Discovery and IP Configuration Tool
User's Manual**

All Rights Reserved

Dissemination or reproduction of this document, or its contents, is not authorized except where expressly permitted. Violators are liable for damages. All rights reserved, for the purposes of patent application or trademark registration.

Disclaimer of Liability

The information contained in this document is subject to change without notice. EtherWAN is not liable for any errors or omissions contained herein or for resulting damage in connection with the information provided in this manual.

Products Supported by this Manual:

eLite Version 1.10

Audience

This manual is designed for the person who installs, configures, deploys, and maintains the Ethernet network.

Document Revision Level

This section provides a history of the revision changes to this document.

Revision	Document Version	Date	Description
A	Version 1	10/4/2019	Version 1.10

Changes in this Revision

Update screenshots and features for eLite V1.10

Contents

PREFACE.....	III
Changes in this Revision	iii
CONTENTS.....	IV
1 INTRODUCTION	5
2 INSTALLATION.....	5
System Requirements.....	5
Install eLite.....	5
3 INTRODUCTION TO FUNCTIONS	6
UI Overview.....	6
Switch Discovery	6
Modify Device Settings.....	8
Firmware Upgrade.....	9
Change Password.....	10
Import Configuration	11
Export Configuration.....	12
Link to Web Configuration	13
Reboot Device	14
4 CONTACT	15



1 Introduction

eLite is a tool used for network discovery and simple configuration such as IP address setup, firmware upgrade and password change for EtherWAN devices.

2 Installation

System Requirements

CPU: Intel Celeron and above

RAM: 1GB

Hard Disk Space: 30MB

Operating System: Windows 10 (32 or 64-bit)

Install eLite

First install the included WinPcap_4_1_3.exe file before operating eLite

WinPcap is the industry-standard tool for link-layer network access, which allows applications to capture and transmit network packets.


Select the location for the program shortcut and click **Next** for the installation.

eLite itself is a standalone executable and does not need to be installed.

Double click on eLite to open the application.


3 Introduction to Functions

UI Overview



Switch Discovery


When you click on the search button, the application will search for all switches on the network. After the search is complete, a window will display all devices that were found. Select a device to see basic info such as model number, firmware version, and MAC address.



NOTE: eLite cannot connect to a switch that has the default IP address of 192.168.1.10. Use the **Modify Device Settings** function to change the default IP address to one that is compatible with your network (see below).



Modify Device Settings

When you click the “Modify” button, a window will pop up in which you can enter the IP address, subnet, and gateway for the device. This button will only appear for devices that have the default IP address. After modifying these fields and clicking the **OK** button, you can click the search button again and see that the switch settings have been changed.



Firmware Upgrade


Select the device for which you want to do a firmware upgrade and then click the  icon. A window will pop up asking for the device password. Enter the root password for the device and click **OK**. A second window will pop up for you to choose the firmware location.



Change Password


Select a device and click the  icon.

Enter the old password, new password, and new password again, then click **OK**.




Import Configuration

Select the device for which you want to import the configuration settings, and then click the  icon. A window will pop up asking for the device password. Enter the root password for the device and click **OK**. A second window will pop up for you to choose the configuration file to import.





Export Configuration

Select the device for which you want to export the configuration settings, and then click the  icon. A window will pop up asking for the device password. Enter the root password for the device and click **OK**. A second window will pop up for you to choose the filename for the configuration file.




Link to Web Configuration

Clicking this icon  will open a browser to the address of the selected switch with the screen shown below.



Reboot Device

Clicking this icon  will reboot the selected device.



EtherWAN System, Inc.
www.etherwan.com

USA Office

EtherWAN Systems Inc.
2301 E. Winston Road
Anaheim, CA 92806
Tel: (714) 779-3800
Fax: (714) 779-3806
Email: support@etherwan.com

Pacific Rim Office

8F., No. 2, Alley 6, Lane 235, Baoqiao Rd.
Xindian District, New Taipei City 231
Taiwan
TEL: +886-2-6629-8986
Email: info@etherwan.com.tw

EtherWAN has made a good faith effort to ensure the accuracy of the information in this document and disclaims the implied warranties of merchantability and fitness for a particular purpose, and makes no express warranties, except as may be stated in its written agreement with and for its customers.

EtherWAN shall not be held liable to anyone for any indirect, special or consequential damages due to omissions or errors. The information and specifications in this document are subject to change without notice.

Copyright 2019. All Rights Reserved.

All trademarks and registered trademarks are the property of their respective owners

eLite User's Manual

October 4, 2019