

EX19164A PoE Switch Installation Guide



1 Unpacking

Unpack the items. Your package should include:

- One EX19164A Ethernet PoE switch
- One AC power cord
- Rack-mounting hardware kit

If items are missing or damaged, notify your EtherWAN representative. Keep the carton and packing material.

2 What Else You Need


- Category 5 or better Ethernet cables
- Small form-factor pluggable (SFP) optical transceiver modules for optional fiber connectivity

3 Select a Location

- Desktop installations: Mount on a flat table or shelf surface.
- Rack installations: Use a 19-inch EIA standard equipment rack that is grounded and physically secure.
- Identify a power source within 6 feet (1.8 meters).
- Choose a dry area with ambient temperature between 0 and 40°C (32 and 104°F).
- Do not cover fans on the rear and side.
- Keep away from heat sources, sunlight, warm air exhausts, hot-air vents, and heaters.
- Be sure there is adequate airflow.

- Keep the switch at least 6 ft (1.83 m) away from the nearest source of electromagnetic noise, such as a photocopier machine.

4 Connect to the Data Ports



Sixteen Gigabit RJ45 Ports

The switch is equipped with 16 10/100/1000 Mbps RJ45 ports that provide IEEE802.3at Power over Ethernet (PoE+), with up to 30W per port (250W total PoE power budget). These ports can be connected to PoE devices such as IP surveillance cameras or Voice Over Internet Protocol (VoIP) phones.


- Insert one end of a Category 5 or better Ethernet cable into a switch port.
- Connect the other end into the Ethernet port of the device.
- Repeat steps A and B for each additional device you want to connect to the switch.

Four Gigabit Combo/SFP Ports

The RJ45 Ports 13 to 16 can be used as combo ports along with four 1000Mbps SFP ports.

The SFP ports accommodate standard SFP modules; wear an ESD-preventive wrist strap before connecting SFP modules.

These combo ports operate in “either/or” fashion. This means that attaching to either an RJ45 or SFP port renders the equivalent partner port unavailable. See the examples below.



5 Apply AC Power

- Connect the female end of the supplied AC power adapter cable to the power receptacle on the switch rear panel. Connect the other end to a grounded 3-pronged AC outlet.
- On the switch rear panel, move the ON/OFF switch to the ON position.

When you apply AC power:

- The fans start.
- The orange **Power** LED goes ON.
- The **Link/ACT** LEDs turn on for every port connected to a powered device.

6 Front Panel LEDs

LED	Color	Status
Power	Orange	ON = switch is receiving power.
PoE <i>(port number)</i>	Orange	ON = Powered Device (PD) is connected.
		OFF = PD is disconnected.
Link/ACT <i>(port number)</i>	Green	ON = valid network connection.
		OFF = no data transmission on port.
		Flashing = port is sending or receiving data.
SFP <i>(port number)</i>	Green	ON = valid network connection.
		OFF = no data transmission on port.
		Flashing = port is sending or receiving data.

NOTES: