

1 Unpacking

Unpack the items. Your package should include:

- > One EX17008A unmanaged switch
- One AC power cord
- > One CD containing this user's guide


If items are missing or damaged, notify your EtherWAN representative. Keep the carton and packing material.

2 What Else You Need

> Category 5 or better Ethernet cables

3 Select a Location

- Desktop installations: Mount on a flat table or shelf surface.
- Rack installations: Use a 19-inch (48.3centimeter) EIA standard equipment rack that is grounded and physically secure.
- Identify a power source within 6 feet (1.8 meters).
- Choose a dry area with ambient temperature between 0 and 40°C (32 and 104°F).
- > Do not cover fans on the rear and side.
- Keep away from heat sources, sunlight, warm air exhausts, hot-air vents, and heaters.
- > Be sure there is adequate airflow.
- Keep the switch at least 6 ft (1.83 m) away from the nearest source of electromagnetic noise, such as a photocopy machine.



The switch is equipped with eight 10/100 Mbps RJ-45 port that provide IEEE802.3at Power over Ethernet (PoE), with up to 30 Watts per port (50

- 57VDC, 600mA Max.) These ports can be connected to PoE devices such as IP surveillance cameras or Voice Over Internet Protocol (VoIP) phones.

- A. Insert one end of a Category 5 or better Ethernet cable into a switch port.
- **B.** Connect the other end into the Ethernet port of the device.
- **C.** Repeat steps A and B for each additional device you want to connect to the switch.

5 Apply AC Power

- A. Connect the female end of the supplied AC power cord to the power receptacle on the switch rear panel. Connect the other end to a grounded 3-pronged AC outlet.
- **B.** On the switch rear panel, move the ON/OFF switch to the ON position.

When you apply AC power:

- All green **PoE** and **Link/ACT** LEDs blink momentarily.
- The fans start.
- > The yellow **Power** LED goes ON.
- The Link/ACT LEDs for every port connected to a device flash, as the switch conducts a brief Power On Self-Test (POST).

6 Front Panel LEDs

LED	Color	Status
Power	Yellow	ON = switch is receiving power.
PoE (port number)	Green	ON = Power Device (PD) is connected.
		OFF = PD is disconnected.
Link/ACT (port number)	Green	ON = valid network connection.
		OFF = no data transmission on port.
		Flashing = port is sending or receiving data.

Congratulations! You have successfully installed your switch.



X17008A	Copyright 2020 EtherWAN Systems, Inc.	Pag
otes:		